



Toyota Yaris 2008

(Sedan Only)

MZ-58-08-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screwdriver, 5/64" bit and drill, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right or Left side of Air Vents

STEP 1. The radio/climate control/air vent bezel is surrounded by a grey plastic trim piece that must be removed. Begin by placing the DTRT between the radio bezel and the grey plastic trim piece directly below the climate control and above the shifter. Use the DTRT in a twisting motion to release two retaining clips securing the trim piece to the dash.



STEP 2. The VSM G3 can be mounted on either the left or right side of the air vents. Choose which side you would like your VSM G3. On each side of the radio/climate control/air vent bezel in another grey plastic trim piece that runs up along each side of the bezel. Use the DTRT in the same manner to release three (3) retaining clips for this trim piece on either the left or right side of the radio bezel.



STEP 3. Once this trim piece has been removed, locate the mounting position of the VSM G3 as pictured in Photo #2. Once you have the VSM G3 in place exactly as pictured, use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. Drill the locations of the pilot holes using a 5/64" drill bit, drilling no deeper than 1/4" inch. Place the VSM G3 over the pilot holes and secure the VSM G3 to the dash using the two provided #8 x 1/2" screws and a Phillips screw driver.



STEP 4. Once the VSM G3 is secure to the dash, place the trim pieces back together in the reverse order in which they were dismantled. You have successfully installed your VSM G3.

Note: Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
 ● ● ○ ○ ○
 Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
 Online at
www.pro-fit-intl.com