

GMC Yukon, Yukon XL 2015-2018
Chevrolet Tahoe 2015-2018
Chevrolet Suburban 2015-2018
PART NUMBER: MZ-71-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 9/32 Socket, Ratchet Socket

PARTS INCLUDED: VSM G3, A Plate, 2-spacer washers

LOCATION: Right of Vent

Step 1: You need to remove the panel to the right of the radio that is above the glove box. Use the DTRT to pop the clips that hold it on (Hint: Easiest way is to start from the bottom of it first.)

Step 2: Use your socket to remove the screw to the right of the vent (Photo #2).

Step 3: Put the screw through the G3 mount hole. Then place the 2-spacer washers on the back side of the G3 mount (Photo #1). Reinstall the screw into its previous location with the G3 placed in the position like in Photo #2.

Step 4: Place the panel back in its original location, starting with the G3 side first.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

[View Instructions & Updates Online at www.pro-fit-intl.com](#)