

Jeep Renegade 2015-2019

PART NUMBER: NS-59-08-G3r

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), T25 torque driver tip

PARTS INCLUDED: VSM G3, J-Stem, Lock Plate, Washer

LOCATION: Right of Radio

Step 1: Using a DTRT, remove the bezel around the radio by slowly working the DTRT around the outside of the bezel popping loose the retainer clips holding it on.

Step 2: Using a T25 torque drive tip, remove the 4 T25 torque screws holding radio.

Step 3: Position the top hole of G3 mount behind the top left screw hole of the radio. Place screw through both radio and mount and reattach radio with the 4 screws.

Step 4: Place trim bezel to original location.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

View Instructions &
Updates Online at
www.pro-fit-intl.com