



Subaru Outback 2006-2009 Subaru Legacy 2006-2009



SU-56-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, Phillips screwdriver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Above and to the right of radio

STEP 1. Insert the DTRT in the lower right hand corner of the air vent assembly between the dash molding and the air vent (Photo #1). Use the DTRT in a gentle twisting motion around the upper cubby hole and air vent assemble in order to release a series of four (4) retainer clips. Disconnect wiring to this assembly and set it carefully aside.



STEP 2. Place the VSM G3 in position, flush to the dash exactly as pictured in Photo #2. Use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. With a 5/64" bit and drill, carefully drill out the marked locations. Do NOT drill more than 1/4" deep. Place the VSM G3 over the pilot holes and tighten it to the dash with the two (2) provided #8X1/2" screws and a Phillips screw driver.



STEP 3. Once the VSM G3 is secure and flush to the dash molding begin to place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3!



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com