

Toyota Tundra 2014-2019

PART NUMBER: SU-70-03-L

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM Legend

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Cordless Drill, Phillips head screw tip

PARTS INCLUDED: VSM Legend, 2 - #8x1/2 screws

LOCATION: Right of Climate Control

Step 1: Using the DTRT pop loose the panel just below the climate controls (Pic1). Do not remove completely, just loose enough for room for your hand to grab the bottom of the climate controls and pull with light pressure to pop retainer clips. No need to disconnect wiring.



Step 2: The mount will be placed at an angle on the right side. The top touching the bottom of the plastic indent and the bottom tip of the mount just above the cut-out opening (Pic3). Mark the 2 larger screw holes and drill pilot holes or using cordless drill attach mount using the screws provided.



Step 4: Reverse Step 1.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

View Instructions &
Updates Online at
www.pro-fit-intl.com