



Toyota Corolla 2009-2011

TY-52-09-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, Phillips screwdriver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of Air Vents

STEP 1. On each side of the radio and climate control is a long trim piece that runs the height of the dash. Insert the DTRT between the trim piece and the dash molding at the very top of the trim piece to the right of the radio. Photo #1. Use a gentle twisting motion to release a series of four (4) retainer clips securing this trim piece to the dash molding. Place this trim piece off to the side.



STEP 2. Place the VSM G3 in place just as pictured in Photo #2. Use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. With a 5/64" bit and drill, drill out the marked locations. Be sure not to drill more than 1/4" deep. Place the VSM G3 over the pilot holes and tighten it to the dash with the two supplied #8 x 1/2" screws and a Phillips screwdriver.



STEP 3. Once the VSM G3 is in position flush and secure, place the trim piece back in place. You have successfully installed your VSM G3.



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ● ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com