



Toyota Tacoma (2005-2013)

PART NUMBER: TY-72-05-L



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit Legend.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool, 5/64" drill bit and drill, # 2 Phillips screwdriver

PARTS INCLUDED: Pro.Fit Legend, instructions, two (2) # 8 x 1/2" screws

LOCATION: Right of climate control

STEP 1.

Insert the dash tool behind the lower-right corner of the climate control panel. Pry outward to release a retainer clip. **Photo 1.** Work the tool around the panel, prying outward until all four (4) clips are released. Let panel hang down. Do not disconnect the wiring.



STEP 2.

Press the Legend firmly against the right side of the climate control cavity. **Photo 2.** Using the screw holes as a guide, mark the location of the top and bottom hole. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. Align the **LEGEND** over the pilot holes, insert two (2) # 8 x 1/2" screws and tighten.



STEP 3.


Re-assemble the dash in reverse order. This completes the installation of your Legend.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this

Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55420, Ph: 952.641.4700 Fx: 952.641.4701



© Pro.Fit International, Bloomington, MN 2006

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**