

## **Toyota** Camry (2018-2019)



TY-72-08-G3

## \*PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3\*

All instructions assume a drives seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properlyy installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screw driver

PARTS INCLUDED: VSM G3, Lock Plate, J Stem, one #10 screw

LOCATION: Bottom Right of Climate Control

Step 1: Starting on the left side of the radio, remove the silver bezel trim that runs from the left side down to the bottom right using the DTRT( this is held with retainer clips). The next piece you will need to remove is the leather bezel that goes from the far right of the dash (piece that is between the glove box and vent) and set aside.

Step 2: Line up the mount with below the screw that holds the radio in place (Photo #2) Mark your hole that you will need to drill to affix the mount to the plastic.

Step 3: Remove the next bezel, which is the piece that runs from the passenger vent by the door and runs to the center council. Start by the far right vent by just pulling towards you. The vent will come out with this piece.

Step 4: You will then need to pop loose the climate control box by just gently pulling. You do not have to disconnect the wires. (Photo 3)

Step 5: Drill the hole that you had marked in Step 2. Attach mount with the screw but leave the mount loose to swing it out of the way to reassemble the dash.

Put the climate control back into place, put the Step 3 piece back into place, spin the mount into place & tighten the screw down to hold it into place, and then reverse Step one to complete the install.



Pro.Fit International, Inc. \* may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. <sup>®</sup> 221 1<sup>st</sup> Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Advanced

View Instructions & Updates Online at www.pro-fit-intl.com