



# Toyota Rav4 2006-2012

TY-73-08-G3



## PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.  
(Some exceptions apply).

**TOOLS REQUIRED:** Dash Trim Removal Tool (DTRT), 5/64" bit and drill, marking pen, Phillips screwdriver

**PARTS INCLUDED:** VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

**LOCATION:** Left of Air Vent

**STEP 1.** To the left of the radio and air vents is a trim piece held in place by a series of three (3) retainer clips. Place the DTRT in the space between the radio and the trim piece below the "scan" button, as indicated by the arrow in Photo #1. With the DTRT, use a twisting motion in order to release the three (3) retainer clips securing the trim piece to the dash molding. Once this trim piece has been released, allow it to hang out of the way.



**STEP 2.** Identify the mounting position of the VSM G3 as shown in Photo #2. Make sure that the VSM G3 is flush with the air vent trim as pictured. Once the VSM G3 is in place, use a marking pen to indicate the location of the pilot holes. Next, with a 5/64" bit and drill, carefully drill out the marked locations. Do not drill any deeper than 1/4". Place the mount over the pilot holes and tighten the VSM G3 to the dash with the two provided #8 x 1/2" screws and a Phillips screwdriver.



**STEP 3.** Once the VSM G3 is tight and flush to the dash molding, assemble the dash in the reverse order it was dismantled. This completes the installation of your VSM G3.



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty  
● ● ○ ○ ○  
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates  
Online at  
[www.pro-fit-intl.com](http://www.pro-fit-intl.com)