Dodge Durango 2010-2017

PART NUMBER: TY-74-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drives seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properlyy installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Electric Screw Driver OR Cordless Drill, Phillips Screwdriver

PARTS INCLUDED: VSM G3, A Plate, 1-#8 x 3/8"

LOCATION: Right of Radio

Step 1: Insert the DTRT in between the radio bezel and the dash molding, Photo #1. Use the DTRT in a gentle twisting motion around the radio bezel releasing the retainer clips. Once the retainer clips have been released, do not disconnect any wiring to the bezel, simply allow the bezel to hang gently out of the way or lay it on the center counsil.

Step 2: Place your mount just above the bottom retainer clip on the right side. When you have located the position for the mount, mark your drill hole location with your marker where the G3 is to be placed. You will need to either drill a hole where this location mark is to insert a screw or you can use your cordless drill to insert the screw.

Step 3: Re-assemble the dash in reverse order. This completes the installation of your VSM G3.







Pro.Fit International, Inc. * may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. [®] 221 1St Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty

View Instructions & Updates Online at www.pro-fit-intl.com