

## Toyota FJ Cruiser 2007-2011

TY-74-08-G3



## PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3


All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips screw driver

PARTS INCLUDED: VSM G3, A Plate, J Stem LOCATION: Right or Left side of Radio

STEP 1. On each side of the radio and climate control is a long trim piece that must be removed (remove only the side you choose to have the VSM G3 mounted to.) Remove and carefully set aside a small Phillips screw located at the very bottom of this trim piece. Next insert the DTRT in the space between this trim piece and the dash molding. Carefully use the DTRT in a twisting motion in order to release the first in a series of three (3) retainer clips. Use your hands to pull the trim piece from the bottom up and out in order to release the two remaining retainer clips at the top.



STEP 3. After the VSM G3 is secure and flush to the dash molding, place the trim piece back in place. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.








Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3<sup>TM</sup>. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876



View Instruction & Updates Online at www.pro-fit-intl.com