

Jeep Cherokee 2014-2019

PART NUMBER: TY-74-08-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a driver's seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and the small hole is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Electric Screw Driver OR Cordless Drill, Phillips Screwdriver

PARTS INCLUDED: VSM G3, A Plate, 1-#8 x 3/8"

LOCATION: Right of Radio

Step 1: Just below the radio, locate the bottom lip of the radio and climate control dials with your fingers and lift it up to remove this piece.

Step 2: Align the VSM G3 on the right side. (Photo #2). Using the G3 as a guide, mark the location of the screw hole that is needed. Set G3 aside. Drill a pilot hole at the marked location using a 5/64" drill bit and drill. Align the G3 over the pilot holes insert the screw provided. *Note* Leave loose to be able to adjust to verify G3 is in the proper location.

Step 4: Replace the radio and climate control dials.



Pro.Fit International, Inc. ® may not be held liable for any damage to a vehicle before, during, or after the installation or removal of this VSM G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc. ® 221 1st Street South, Montgomery, MN 56069, Ph: 507.364.7773 or 800.388.0073

Installation Difficulty



Simple

Advanced

©Pro.Fit International, Inc. Montgomery, Minnesota 2017

[View Instructions & Updates Online at www.pro-fit-intl.com](#)