



**INSTALLATION INSTRUCTIONS**  
**LEXUS LX470 (1998-2002)**  
**TOYOTA LAND CRUISER (1998-2002)**  
**PART NUMBER: TY-74-98**

**VIEW INSTRUCTIONS & UPDATES  
 ONLINE @  
 WWW.PRO-FIT-INTL.COM**

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.**  
 All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** #2 Phillips screwdriver, hook tool, 5/64" drill bit and drill, marking pen.

**PARTS INCLUDED:** Pro.Fit VSM™, instructions, three (3) #8x1/2" screws.

**LOCATION:** To the right of the climate control.

**STEP 1.**

Begin by removing the trim bezel that surrounds the radio. This trim bezel also has the climate control integrated into it. Insert the hook tool behind the trim bezel in between the bezel and the dash pad in the upper right corner of the bezel. Pull toward you to release top right clip. Perform this same action approximately on the top middle part of the bezel releasing middle clip. Continue working the bezel loose with the hook tool counter clockwise, all the way around the bezel releasing a total of eight (8) clips. **Disconnect all wiring to the bezel.** Set the bezel aside.



**STEP 2.**

Locate a flat spot of plastic just below the middle right side clip hole. Lay the Pro.Fit VSM™ over this flat spot. Using the holes in the Pro.Fit VSM™ as a guide, mark three (3) spots for drilling pilot holes and set the mount aside. With the drill and 5/64" drill bit, **carefully** drill three (3) pilot holes. Align the holes in the Pro.Fit VSM™ with the pilot holes. Insert the the provided screws and tighten with the #2 Phillips screwdriver.



**STEP 3.**

Re-assemble the dash in reverse order securing all wiring and clips. Install your hang-up cup onto the Pro.Fit VSM™.



This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876  
 Web Address: [www.pro-fit-intl.com](http://www.pro-fit-intl.com)