

## Toyota Sienna 2004-2010

TY-91-04-G3



## PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

## When properly installed, the metal between the ball and 2 small holes is all that is exposed. (Some exceptions apply).

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, Phillips screwdriver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of Climate Control

STEP 1. Insert the DTRT in the lower right hand corner of the trim bezel to the right of the climate control. Photo # 1. Use a gentle twisting motion around this trim bezel to release a series of three (3) retainer clips. Do not disconnect the trim bezel; simply allow it to hang out of the way.

STEP 2. Place the VSM G3 in position just as pictured, Photo #2. Once the VSM G3 is in position and flush to the dash molding, mark the locations of the pilot holes with a marking pen. Use a 5/64" bit and drill to drill out the marked locations. Do not drill more than 1/4" deep. Place the VSM G3 over the pilot holes and tighten the VSM G3 evenly to the dash molding with the two (2) provided #8 x 1/2" screws and a Phillips screwdriver.

STEP 3. Once the VSM G3 is flush and secure, simply replace the trim piece. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.







Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3<sup>TM</sup>. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

