



UltiMount S2

PART NUMBER: UL-222

Pre-Installation Tips

Before installing the UltiMount S2 determine the position where it will work best for the primary user. **Attach a holder or cradle** along with the electronic device to the UltiMount S2 prior to exploring the ideal position for mounting. Some electronics may include a holder for a vehicle application, and if so, it will usually attach directly to the UltiMount S2

Important: The flex pad adhesive is a one-time stick application. Therefore, it is best to determine the mounting position for the UltiMount S2 prior to installing. Once the flex pad is adhered to the mounting surface, it cannot be repositioned. Be sure to complete all surface preparation steps before installing UltiMount S2.

Installation Instructions

Please read all instructions thoroughly before installing this product.

Contents: UltiMount S2, Surface Preparation Packet, Alcohol Prep Pad

Helpful items to have: Clean dry cloth

Important: Clean the surface where the UltiMount S2 will be installed with the Surface Prep Packet to remove the silicone emulsions such as Armor All®. Do not apply adhesive to leather surfaces. Do not install the UltiMount S2 where it could block your vision, airbags, gear shifter, climate controls, steering wheel, radio controls, or other amenities that may interfere with safe operations of the vehicle.

Step One:

Position and select the best mounting location on the dash or console of the vehicle where the UltiMount S2 is to be installed.

Step Two:

Prepare the mounting surface by cleaning the mounting location with the Surface Preparation Packet provided. Wipe an area slightly larger than the flex pad in only one direction and do not use a circular motion. Dry the area with a clean, dry cloth. Wipe dry in the same direction as above.

Clean the same area with the Alcohol Prep Pad provided. Wipe in the same direction as above, dry with a clean cloth and allow to air dry completely.

Note: The alcohol may leave a film on the surface. Wipe clean with a dry cloth.

Step Three:

It is best to remove the flex pad from the UltiMount S2 before adhering. Remove the flex pad from the gray ball and stem with a phillips screwdriver. Access this screw through the hole in the gray ball. Remove the liner from adhesive pad and adhere it to the mounting position. Apply firm pressure to the center and edges of the flex pad for a minimum of 1 minute. Let adhesive cure for 72 hours before reattaching the UltiMount S2.

Ideal installation temperature is between 60° and 80°F.