



VOLKSWAGEN BEETLE (1999-2005)

PART NUMBER: VW-52-98

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: T-30 Torx bit & driver, 1/4" x 1/4" drive swivel socket, ratchet and small extension.

PARTS INCLUDED: Pro.Fit VSM® mount, instructions.

LOCATION: To the right of the radio, behind the passenger grab bar.

STEP 1. Begin by locating two black plastic covers on the right and left sides of the passenger grab bar. Insert the hook tool behind the cover that is on the right side of the grab bar. Pull back toward you to release two compression style clips that hold the cover in place. Set the cover aside. Perform this same action on the cover that is on the left side of the grab bar and set that cover aside.

STEP 2. Using the T-30 Torx bit and driver, locate and remove two Torx screws that hold the grab bar in place. Carefully remove the grab bar from the dash. **NOTE: Part of the grab bar is inserted into the right side of the center dash section that has the radio and climate control integrated into it.** Holding the grab bar in one hand, insert the Pro.Fit VSM® behind the grab bar over the left side mounting hole. Place the grab bar back into position.


STEP 3. Replace the two factory screws that hold the grab bar in place and tighten using the 1/4" swivel socket, T-30 Torx bit, ratchet and extension. **Note:** The swivel socket will allow you to create the correct angle to tighten the left Torx screw.

STEP 4. Replace the black plastic cover on the left side of the grab bar by sliding it behind the face of the Pro.Fit VSM® and back into position. Replace the black plastic cover on the right side. Install the phone holder onto the Pro.Fit VSM®.

This completes the installation of your Pro.Fit VSM®.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© Pro.Fit International, Eagan, MN 2005

