

mini cord channel

HOLD AND GUIDE CHARGING CABLES

utwire®

WARNING:

- (1) Please do not overload the channel. Cords should not be exposed.
- (2) Turn off power and unplug all power wires prior to installation.
- (3) This product is not to be used for hard-wired electrical wiring.
- (4) For use in dry and indoor locations only.

INSTALLATION INSTRUCTIONS:

For best results, please DO NOT open the slit for the channel prior to taping the Mini Cord Channel on the wall in step 8.

- (1) Measure and plan the route.
- (2) Wipe clean and dry the area of wall for the route.
- (3) Cut the Mini Cord Channel to the desired length with a pair of scissors.
- (4) Peel off the tape liner.
- (5) Apply the Mini Cord Channel to the wall. Slit should face the top.
- (6) Press firmly across the length of the Mini Cord Channel for 30 seconds.
- (7) Wait 15 minutes for the adhesive bond to set before inserting cords.
- (8) Press gently to open the slit with your fingers and insert cords.

