

The **MTNTK** BlowHole

Arctic Cat Wildcat Trail & Sport 700
Installation Instructions



Disclaimer: Never attempt to adjust or run engine with fan on. Do not stick your fingers into the fan housing as it will cut or dismember. Mountain Tek Performance is not responsible for damages incurred by using this product or improper installation.

208.652.0122

MTNTKperformance.com



2. Install Blow Hole as shown onto the clutch cover with straight silicone towards the clutch cover. Align MTNTK graphics as shown. This will insure proper routing. Use the stock clamp and fasten the Blow Hole to the clutch cover.



4. Locate the stock accessory plug and insert the Blow Hole harness plug: Red to Orange, Black to White. This allows you to still use the factory accessory plug. Reinstall Driver's seat.



1. Remove Driver's seat. Locate rubber duct located on top of the clutch cover. Loosen hose clamp and remove rubber duct. You will re-use the hose clamp.



3. Carefully route the Blow Hole wiring harness down the factory harness and under the driver seat towards the front of the machine. Secure wires so they do not rub.