



1. Locate the clutch housing intake tube and loosen clamp on clutch cover. Then remove intake tube from both intake and clutch cover.



3. Cut completely through the intake tube at the correct mark. Be sure to keep your blade straight so you can achieve a straight cut.



5. Install the Blow Hole in line with the cut intake tube as shown. Keep clamps loose. Install intake tube into stock location on the clutch cover. Once aligned, tighten clamps.



2. Measure 10" from the straight end of the intake tube and mark using a white marker.



4. Measure 5 1/2" from the cut you just made towards the bottom of the intake tube. Mark using a white marker. Cut completely through the intake tube at this mark.



6. Route wiring harness along the bed so it is up and out of the way. **Plug directly into the taillight as shown.** Be sure the wires will not rub, chafe, or melt. Use zip ties to secure wiring harness.