

The **MTNTK** Blow Hole

'12-'19 Arctic Cat WildCat X
Installation Instructions

Disclaimer: Never attempt to adjust or run engine with fan on. Do not stick your fingers into the fan housing as it will cut or dismember. Mountain Tek Performance is not responsible for damages incurred by using this product or improper installation.

208.652.0122

MTNTKperformance.com



2. Install the Blow Hole into the access panel. Slide the 90° silicone over the upper CVT Intake Duct. (See Step 3 Below)



4. Route the Blow Hole wire harness under the center console and up behind the dash. Make sure to route the wire away from the drive system. Secure harness using zip ties.



1. Remove seats, center access panel and center console. Disconnect and remove the battery.



3. Tighten the clamp onto the CVT intake duct.

Panel Removed for Clarity



5. Locate the 2-Wire Accessory Plug under the dash. It is located directly behind the speedometer. Plug the Blow Hole Harness into this Accessory Plug.