



The '13-Current Ski-Doo Brake Reservoir Cover Instructions



1. Remove brake lever bolt.



2. Remove the brake reservoir clamp bolt.



3. Slip reservoir cover over brake line and on top of brake reservoir as shown.



4. Install included brake lever bolt. Tighten remaining mounting bolt. This may fit tight.

Kit Contents:

- 1 - MTNTK Performance Brake Reservoir Cover
- 1 - Shoulder Bolt

MTNTKperformance.com