



Ahead of the Curve®



# Stealthbox®

INSTALLATION GUIDE  
for the

## SB-T-4RNRG5/10TW3

SKU# 94685

2010 & Up Toyota 4Runner

**Enclosure Type:** Sealed

**Driver Type:** 10TW3-D4

**Nominal Impedance:** 2 ohms

**Continuous Power Handling:** 400 watts (RMS method)

SB-T-4RNRG5/10TW3 INSTR\_SKU# 011555

### ! IMPORTANT

- Installation requires appropriate tools and safety equipment. Professional installation is recommended.
- If you prefer to perform your own installation, please read this installation guide completely before beginning.
- Before cutting or drilling, check for potential obstacles behind mounting surfaces.
- Mount this product securely to prevent damage or injury in severe conditions.

### INSTALLATION DIFFICULTY:

3 OUT OF 5

ESTIMATED TIME:  
2 HOURS

