



**BERNINA**  
OF NAPERVILLE •

**KIMBERBELL**<sup>®</sup>  
SOCIETY

May 2023: Butterfly Tool Pouch

# Additional Supplies

Bobbin thread:

- A full bobbin wound with Isacord #0003
- A ¼ bobbin wound with Isacord #0520

[Expert Stabilizer Tape](#)

[Bodkin for Threading Ribbon](#)

[Iron](#)

Standard Sewing Foot #1C



## Additional Supplies

Hoop Size: 6x10 (BERNINA Maxi/Mega Hoop)

Batting and Stabilizer:


- (1) 21" AquaMesh
- (2) 6.5"x10" Fusible woven
- (1) 6.5" x 10" WashAway Topping

Recommended Thread:

- 2922-4174 [Isacord Charcoal \(Dk Gray\)](#)
- 2922-0003 [Isacord Ghost White \(White\)](#)
- 2922-0520 [Isacord Daffodil \(Yellow\)](#)
- 2922-5115 [Isacord Baccarat Green \(Green\)](#)
- 2922-4515 [Isacord Spruce \(Blue\)](#)


Fabric:

- F8: [Dear Stella: Sew Lovely-White](#)
- F8: [FOLK FLORAL: Cross stitch on autumn orange](#)
- F8: [Pure Solids Icy Mint \[PE-451\]](#)



# Part 1: Embroidering the Butterfly Tool Pouch Design

1. 




- Iron **Fusible Backing** to the **wrong side** of the Inner Wing Fabric. **Note: Do NOT use Fusible Backing on the rest of the fabric in this project.**

2.




- Hoop the **Wash-Away Stabilizer**.

3.



- Load the embroidery file into the machine.

4.



- 1 Stitch the Front Placement Line.  
Isacord #0003

5.



- Place the Front Fabric **right side up.**

6.



- 2 Stitch the Front Tack-down Line. **Do NOT trim the fabric at this time.**  
Isacord #0003



3 Stitch the Inner Wing Placement Line.  
Isacord #0003



- Place the Inner Wing Fabric **right side up**.



4 Stitch the Inner Wing Tack-down Line.  
Isacord #0003



- Trim the fabric close to the stitch line.




5 Stitch the Mesh Wing Trimming Line.  
Isacord #0520




- Trim the Front Fabric **inside** the trimming line. **Be careful not to cut the stabilizer.**



-  **6** Change the bobbin thread to match the top thread. Stitch the Mesh Wing Fill.

Isacord #0520




-  **7** Stitch the Mesh Wing Satin Outline and Detail.

Isacord #0520

# DON'T FORGET TO PUT YOUR TOPPER DOWN !




 **8** Change the bobbin thread back to a neutral color. Stitch the Outer Wing Placement Line.

Isacord #5115

- Cover the design with **Wash-Away Topping** to prevent cutting the satin stitch while trimming the leather.

- Place the Outer Wing Leather **right side up** over the **Wash-Away Topping**.



 **9** Stitch the Outer Wing Tack-down Line.  
Isacord #5115





- Trim the leather close to the stitch line.





-  **10** Stitch the Inner Wing Detail.  
 Isacord #4515



- Tear away the excess topping.




-  **11** Stitch the Body Fill.  
 Isacord #4174



-  **12** Stitch the Drawstring Openings.  
 Isacord #0003




- Using a seam ripper, carefully cut open the center of each drawstring opening. **Optional:** Put a drop of fray preventive product on the cuts to prevent fraying.



- Place **(1)** Lining Fabric **right side down**, with one **short** edge approximately  $\frac{1}{2}$ " above the **top** edge of the Front Tack-down Line stitched in **Direction Step 6**, completely covering the project.

26.



13

Stitch the Seam  
Stitch Line.



Isacord #0003

27.




14

Stitch the Pouch  
Cut Line with a  
visible thread.



Isacord #0003




- Remove the hoop from the machine. Cut all layers of the fabric and stabilizer directly on the cut line (shown in **black**), extending 1/2" on each end (shown in **yellow**). **Do NOT cut the seam stitch line.**



- Lift the Lining Fabric **up**, and tuck it through the slit cut in the fabric and stabilizer.

30.



- Turn the hoop to the **back**. Pull the Lining Fabric **down** with the **right side up**.
- Press the seam well. Smooth the Lining Fabric and tape the sides and corners in place.

**Note:** Be sure that the Lining Fabric is not showing on the front of the hoop. When pressing fabric in-the-hoop, use a mini iron or finger press well along the seam line. If you are using an iron, press on an ironing board. **Do not use steam or water when pressing the Wash-Away Stabilizer.**




Return the hoop to the machine.  
Stitch the Lining Tack-down Line.  
Isacord #0003



Stitch the Drawstring Casing Lines.  
Isacord #0003

33.




- Place the Back Fabric **right side down**, covering the entire project. **Be sure that the cut in the stabilizer is completely covered.**

34.




Stitch the Back Fabric Tack-down Line.

Isacord #0003



- Remove the hoop from the machine. Turn the hoop to the **back**. Place **(1) Lining Fabric right side down**, covering the entire project. Tape the corners in place. **Be sure that the cut in the stabilizer is completely covered.**



Stitch the Final Outline. This will leave an opening for turning and two openings for the drawstrings.

Isacord #0003




37.



- Remove the project from the hoop. Remove all tape. Trim the fabric  $\frac{1}{4}$ " away from the Final Outline Stitch.

38.



- Clip the corners to reduce bulk.
- Trim across the corner seam allowance, being careful not to cut through the stitches.
- Trim again at a slight angle, from the corner up the seam allowance, about 1" on each side to reduce bulk.



- Turn the project through the opening in the lining to expose the inside of the pouch. Gently poke the corners and seams with a blunt tip to square.

- For a finished look, fold the raw edges in and use a needle and thread to sew the opening closed.


- Turn the pouch **right side out**. Gently poke the corners and seams with a blunt tip to square.

**PLEASE NOTE:** We set our sewing machine up for free arm sewing and stitched a casing on the back piece. Be sure that there is at least 5/8" between the casing lines for the ribbon to fit easily.

## Part 2: Threading the Drawstrings



- Using a safety pin, attach **(2)** pieces of crocheted edge trim together. Both pieces of trim should be **right side up**. Thread both pieces through the drawstring casing of the pouch. **Note:** The pictures show two colors of trim for illustration purposes only. You will use the same color of trim.



- Remove the safety pin.



- Pull **(1)** trim end from each side of the pouch. This will create a long end and a short end on each side.



- Turn the pouch over so that the **back** is facing you. Attach the safety pin to the longest piece of trim on **(1)** side.



- Insert the trim through the small opening in the side seam, easing the safety pin through the **back** of the pouch, pulling the trim through to the other side. Remove the safety pin.
- **Note:** To ease the trim through the casing, insert a small stick and push against the safety pin.



- Thread the second long piece of trim through to the other side of the pouch by repeating **Part 2, Direction Steps 4 and 5**.

7. 



- Rinse the project with cool water to remove the stabilizer from the mesh wing. Lay flat to dry.
- Using a pressing cloth, press well.

8.



- On each side of the pouch, tie the ends of the trim together in a knot.