

### ASSEMBLY INSTRUCTIONS

1. Assemble handle to rose and rotate clockwise over 1/4 turn
2. Assemble detent bush locating over lug on handle shaft
3. Assemble spindle to retainer plate by inserting into centre hole and moving spindle sideways to locate in groove
4. Assemble retainer plate/spindle to handle/rose by inserting spindle into square hole in detent bush and locating retainer plate in rose, with location hole aligned with boss
5. Insert screw into one of the three holes to suit movement required (A, B, or C/S) and tighten a maximum torque of 1.0Nm
6. Check function and assemble barrel to handle as required

### SPINDLES

TYPE CODE	LENGTH	PLAIN	THREADED
B	32mm	T/SPIN/B2	
L	32mm		T/SPIN/L2
M	40mm	T/SPIN/M2	
C	44mm	T/SPIN/C2	
D	50mm	T/SPIN/D2	
T	50mm		T/SPIN/T2
N	62mm		T/SPIN/N2
E	75mm	T/SPIN/E2	
H	100mm	T/SPIN/H2	
F	136mm	T/SPIN/F2	

