

Instructions for kit assembly.

Pour powder into the cup. Add water and stir until all lumps disappear. Pour evenly into molds, leaving about ¼ inch of space. Lightly tap the mold on the table several times to release air bubbles. Screw three nuts onto each bolt. Press one bolt into each of the 4 cavities. Add a magnet and push into the plaster until it is even with the edge of the mold. If plaster overflows, use your finger or popsicle stick to wipe off the excess. Don't worry too much if you get plaster on the magnet. It can be scraped off later. Place a popsicle stick over two of the cavities and place two magnets on top of the popsicle stick over magnets in the slugs. This will keep the magnets near the surface, which will keep them from sinking to the bottom.

Allow to set for at least 30 minutes.

Push up on the bottom of the mold, avoiding pushing on the ears so as not to break them.

Paint as desired, avoiding the magnet. Allow to dry.

Apply top coat, avoiding the magnet again. Allow to dry.

!!Do not dump in sinks!!!