FLOOR DECALS

Floor decals are best suited for hard surfaces such as sealed wood, ceramic tile, vinyl, and concrete. Place the decal on as smooth a surface as possible for best results.

HOW TO APPLY

STEP 1 • PREPARE THE SURFACE

Thoroughly clean the surface where you plan to place your floor decal. Ensure that no residue, dust, or moisture is remaining on the surface.

For painted surfaces, please test the decal adhesive in an inconspicuous area to ensure the paint will not lift during removal.

STEP 2 • INSTALL THE FLOOR DECAL

Remove the paper backing from the floor decal and place in desired location. Use a squeegee to push any air bubbles from the center of the decal toward the edges. A credit card or similarly flat object can be used for this but be sure not to press too hard to avoid scratching the surface of the decal. For best results, please allow the floor decal to set for 12-24 hours before heavy traffic.

To remove floor decals, gently lift edge of decal and slowly peel back. Use cleaning detergent to remove any adhesive residue left behind.

TIPS FOR INSTALLATION

Watch out for condensation and moisture-holding zones.

Before you install the decal, look for areas where condensation typically occurs, such as near holes and cracks. If identified, fill these areas to prevent moisture and condensation. Allow 24 hours for filling to dry. Once dry, smooth out the filling and clean the area so the decal will lay evenly across the surface.

Be mindful of surface type.

When installing on concrete or asphalt, avoid covering release channels. Release channels ensure the surface will not shift or crack as temperature changes. If obstructed or sealed off, a change in temperature can cause the surface to crack.

When selecting an area on vinyl or tile, avoid installing the floor decal over a tile edge or grout lines. These areas can house air bubbles that can negatively impact the longevity of your decal and result in prematurely peeling.

When installing floor decals on wood or wood laminate, avoid floor end joints. The presence of these joints will make the wood floor decal look irregular and bumpy.

LET'S WORK TOGETHER AND MAKE YOUR BUSINESS AS WELCOMING AND SAFE AS POSSIBLE!

CHECK OUT OUR DESIGNER COLLECTIONS
HEYTHERESIGNS COM

