

art. K 603

SCHIENALINO PER K 28
BACH-REST FOR K 28
DESSERET POUR K 28

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS

INSTRUCTIONS DE MONTAGE



N°	DESCRIZIONE DEL KIT KIT DESCRIPTION DESCRIPTION DU KIT	QUANTITÀ QUANTITY QUANTITÄ
1	SCHIENALINO BACH-REST DESSERET	1
2	VITE TL M 6 X 16 SCREW M 6 X 16 VIS M 6 X 16	2

PRIMA DI FORARE VERIFICARE CHE LA DIMA CORRISPONDA ALLE MISURE INDICATE
BEFORE DRILLING HOLES CHECK THAT MEASURES ON TEMPLATE CORRESPOND
AVANT DE PERCER CONTROLER QUE LE GABARIT CORRESPOND AUX MESURES INDIQUEE
BEVOR DER KOFFERDECKEL DURCHBOHRT WIRD PRÜFEN SIE DABß DIE SCHABLONE DEN GEGEBENEN
ABMESSUNGEN ENTSPRICHT

ANTES DE HACER LOS AGUJEROS COMPROBAR LAS MEDIDAS DE LA PLANTILLA CORRESPONIENTE

⊕ $\phi 6.50$

$\phi 6.50$ ⊕

141 mm

. Dima
. Template
. Gabarit

