



# WOODPLANK FLOORING

## *INSTALLATION GUIDE*

When installing our Modern White Oak Wide Plank flooring, we recommend a standard glue-down installation. Here's an outline of the recommended installation steps below.

### **MATERIALS YOU WILL NEED:**

1. WoodPlank Flooring
2. Flooring Adhesive
3. Trowel
4. Mallet
5. Pry Bar
6. Circular Saw or Table Saw
7. Spacers
8. Flooring Nailer (optional)

### **STEP-BY-STEP INSTALLATION GUIDE:**

#### Step 1: Prepare the Subfloor

Ensure your subfloor is clean, dry, and level. Any dirt or moisture can prevent the adhesive from bonding properly, and an uneven surface can lead to problems down the line.

#### Step 2: Layout Planning

Determine the direction and pattern of the floor planks. The planks are typically installed parallel to the longest wall in the room for the best visual effect.

#### Step 3: Apply Adhesive

Spread the flooring adhesive onto the subfloor using the trowel. Only cover a small area that you'll be able to cover with the flooring before the adhesive dries.

#### Step 4: Install the Planks

Begin laying the planks, starting from one corner of the room. Press each plank firmly into the adhesive and ensure a tight fit with the neighboring plank. Remember to leave a small expansion gap between the planks and the wall; you can use spacers to maintain this gap.

### Step 5: Extra Hold (Optional)

While not necessary in all cases, some installers prefer to add nails for additional support. If desired, use a flooring nailer to insert nails at an angle through the tongues of the planks.

### Step 6: Continue the Process

Repeat the adhesive application and plank installation process until you've covered the entire floor. You'll likely need to cut the last plank in each row to fit; you can use a circular saw or table saw for this.

### Step 7: Clean-up

Wipe away any excess adhesive that squeezes out between the planks before it dries.

### Step 8: Let it Set

Allow the adhesive to dry fully (according to manufacturer's instructions) before walking on the floor or adding furniture.

Remember, this is a simple guide and individual projects may have specific requirements or challenges that need to be addressed. It's always a good idea to consult a professional if you're unsure about any aspect of the installation process.

