



**KINGPIN Fab**  
**MARBURG**  
**QLD 4346**  
**AUSTRALIA**  
**0466 303 137**

---

## ABS BRAKE LINE FITTING:

---

WHEN FITTING THE **TWO** REAR LINES IN YOUR FOUR LINE BRAKE HOSE KIT, YOU WILL NOTICE THAT THE ONE FEMALE FITTING WHICH GOES TO THE CHASSIS END **DOES NOT** FIT THROUGH THE HOLE IN THE CHASSIS BRACKET IN ORDER TO FIX IN PLACE WITH THE HORSE-SHOE CLIP.

ALL AFTERMARKET LINES ON THE MARKET REQUIRE YOU TO FILE OUT THIS HOLE LARGER, FOR THE FITTING TO PASS THROUGH. YOU CAN USE A ROUND FILE, DIE GRINDER, OR EVEN A 16mm DRILL BIT IF YOU HAVE ONE.

THE JOB IS EASY AND SHOULD NO PRESENT ANY PROBLEMS :)

