

SETUP GUIDE

Here is a quick guide for setting up your tracker :

- 1- Active the sim card on a **prepaid or postpaid Mobile plan** of your choice that can take calls and text, with at least 2-3 GB Data per month.
- 2- Put the sim card in an active phone to ensure that its sending msgs and making calls
- 2- Open the silicon lid and pop the sim tray out
- 2- Install the micro Size Sim card in the sim tray by right placement ,noticing cut edge of the sim
- 3- Check the connector connected properly to the car fuse slot in the fuse box (you will find the fuse box normally under the steering wheel)
- 4- All three LED lights should be glowing and the tracker is ready
- 5- Download the Tracksolid Pro App from the App or Play Store
- 6- Create your account or Login to your existing account
- 7- Navigate to 'Devices' and select the + button in the top right corner, using the IMEI on the underside of the device to register your tracker
- 8- If you cannot find the + button from step 5, navigate to the Tracksolid Pro website <https://tracksolidpro.com/mainFrame> and login, select DEVICE at the top and the 'Bind Device' option. Enter your IMEI and the tracker will be visible from both web and app account or by scanning the QR-Code from the tracker of the tracker

Please follow the steps and you will be good to go :)