

McGAUGHY'S UPPER CONTROL ARM INSTALLATION GUIDE



When installing the new McGaughy's upper control arms, the "M" badge will be towards the front of the vehicle.

Also, do not forget to grease the ball joints after installing the new upper control arms.



www.mcgaughys.com