

Installation Recommendations

For Stone Pavers

BEFORE INSTALLATION

Please check with your engineer and installer first for installation related products, including Waterproofing, Stone Sealers, Setting Materials, etc.

Here below are for reference only,

Waterproofing : Mid-Atlantic Waterproofing ; Mapei

Stone Sealers : Weiman; Black Diamond; Stonetech

Setting Materials: Mapei; TEC

Adhesive :

- Exterior application: a flexible latex based mortar system suitable for the stone is recommended.
- Interior application: a thin set mortar suitable for the stone is recommended.
- For light colored stones, a white mortar is recommended.

After you determine which of their products are appropriate for your specific project, as well as for installation assistance and accurate

drawings. To follow the latest installation practices and methods, please always refer to local building codes and the Tile Council of America (TCNA).

INSTALLATION

- Before installation, please make sure that the back of the stone are clean and free of dust or dirt.
- Do not mark the surface of the stone with permanent markings, as these marks will be absorbed by the stone and cannot be removed.
- To clean natural stone by water only. Do not use alkaline or acid based cleansers, as well as after installation.
- Cut the stone only with a wet saw with carbide or diamond tip blades.
- Cutting stone will create dust, so it should be worked outside.
- Please clean the back of the stone by water after cutting.
- To wipe the back of the stone with a damp duster cloth is recommended.
- To pre-layout the stone pavers before installation according to your personal preference is recommended.
- Contractors or engineers can provide important information on local building codes, seismic building codes, and institutions building codes and installations.