

# Stroba™ Quick Start Guide\*



1. PLACE STROBA™ IN YOUR MASON JAR



2. USE THE EXISTING RETAINING RING TO FASTEN STROBA™ SECURELY IN PLACE



## Open Stroba™



1. ROTATE KNOB ON DIAL OF MIDDLE LID (D) LEFT TO OPEN



2. PUSH UPPER PLUNGE STRAW (B) DOWN FOR BETTER AIRFLOW

## Close Stroba™



1. GENTLY PINCH THE TWO SIDES PINS ON THE UPPER PLUNGE STRAW (B) UPWARDS



2. ROTATE KNOB ON DIAL OF MIDDLE LID (D) RIGHT TO CLOSE



## Disassemble Stroba™

- 
1. PULL UPPER PLUNGE STRAW (B) OUT OF TOP LID (C). CAPPIE™ (A) CAN BE CAREFULLY REMOVED FROM UPPER PLUNGE STRAW (B) IF NEEDED
- 
2. REMOVE SILICONE SEAL (G)
- 
3. PUSH DOWN ON TOP LID (C) TABS TO REMOVE
- 
4. PUSH DOWN ON TABS ON LOWER LID (E), AND PUSH UP IN THE CENTER TO REMOVE MIDDLE LID. (MAY NEED TO WORK YOUR WAY AROUND RIM TO LOOSEN OR PULL ON THE KNOB).
- 
5. SLIDE OFF EXTENDER STRAW (F)

## Assemble Stroba™

- 
1. REPLACE O-RING (H) ON GROOVE OF MIDDLE LID (D) IF NEEDED
- 
2. PUSH MIDDLE LID (D) INTO LOWER LID (E) VIA CENTER PIN. ROTATE TO ENSURE O-RING (H) IS SECURE IN LOWER LID (E)
- 
3. SNAP TOP LID (C) IN PLACE VIA LOWER LID (E) CENTER PIN. LINE UP MAIN STRAW HOLE ON LOWER LID (E) WITH TOP LID (C) HOLE.
- 
4. INSERT CAPPIE™ (A) ONTO LONGER END OF UPPER PLUNGE STRAW (B) IF NEEDED.
- 
5. INSERT UPPER PLUNGE STRAW (B) INTO TOP LID (C). LINE UP GUIDE PINS ON UPPER PLUNGE STRAW (B) WITH SLOTS ON TOP LID (C) CROWN.
- 
6. INSERT SILICONE SEAL (G). INSERT EXTENDER (F) SLOT ONTO LOWER LID (E) PIN FOR 28OZ AND 32OZ WIDE MOUTH MASON JARS.

## Stroba™ Parts List



CAPPIE™ (A)



UPPER PLUNGE STRAW (B)



TOP LID (C)



MIDDLE LID (D)



LOWER LID (E)



EXTENDER (F)



SILICONE SEAL (G)



O-RING (H)

## ⚠ Warning ⚠



⚠ Do not hold Stroba™ upside-down for long periods at a time. Pressure build up can potentially cause slow drippage.

