

CONCRETI

Please read carefully

INSTALLATION GUIDE

Wall Mounted Sinks

Tools

- Measuring tape
- Level
- 100% silicone
- Carpentry tools
- Pencil

Installation

1. Measure the distance between the floor and the desired height where the sink will be mounted.
2. Check for studs which the wall mount will be attached to.
3. Mark the screw holes in a manner that the wall mount is level.
4. Attach the wall mount to the stud using a wood lag bolt, use a washer in between.
5. Make sure the attached wall mount is secure and sturdy enough to withstand the weight of the sink.
6. Apply 100% silicon on the surface of the wall mount and place sink on top. Wipe any excess silicon off.
7. Wait 24 hours to let silicon dry.

Disclaimer - We highly recommend you consult a professional before installing your Concretti Designs sink. If you are not a professional we do not recommend you to attempt to install your Concretti Designs sink without guidance or supervision. Handle with care.