



SOUND
INSULATION



IMPROVED
COMFORT

BIYORK

UNDERLAYMENT SERIES

UNDERTONE GREY 1.5 mm EVA INSTALLATION INSTRUCTIONS

BEFORE YOU BEGIN

TECHNICAL SPECS

- Material composition: High Density EVA
- Material Thickness: 1.5mm
- Length: 8.4m (Continuous Rolls)
- Width: 1.1m

ACCLIMATION

- Prior to installation verify that you have received the correct product and quantity.
- Store Undertone Grey in a clean and dry location

TOOLS REQUIRED

- Tape Measure
- Metal straight edge
- Utility knife and extra blades

PREP WORK

UNDERTONE GREY and the flooring material must acclimatize, in their sealed packaging, in the room where they are installed for at least 48 hours, at temperature of at least 65°F.

Before starting installation make sure the sub floor is permanently dry and free of dirt, dust, grease and other foreign matter. Concrete must be free of efflorescence and not subject to hydro-static pressure. Sub floor moisture percentages should not exceed the flooring manufacturer's or Impact Technical Services recommendations.

INSTALLATION

PLY-WOOD CONSTRUCTION

Sub floor should be properly leveled, structurally sound and clean. Plywood sub flooring should be of a good grade. Variations in floor level over 1/8" within

3 feet span should be leveled before installing UNDERTONE GREY. Any nails or other protrusions should be pounded flat or removed.

CONCRETE SLAB

Inspect concrete sub floor for any open cracks and fill with a high grade patch. Remove any excess concrete lumps or residue that may interfere with the installation of UNDERTONE GREY. The concrete slab should be permanently dry. Good quality concrete waterproof sealer may be required if moisture in slab is too high.

INSTALLATION UNDER GLUE DOWN

UNDERTONE GREY needs to be adhered to the sub base. Recommended adhesive: Follow the local dealer's advice. Install UNDERTONE GREY rubber in opposite direction to the sub base. Start in a corner and roll out UNDERTONE GREY installing it flush to the wall. Roll up the roll halfway and apply adhesive on exposed area, roll back over adhesive and flat trowel any air pockets, continue with other side the same way. Continue rolling out and gluing down UNDERTONE GREY in the same manner until the entire area is covered. Make sure the edges are tightly butted together, both side by side & end by end. Use a 50—100 lb roller to fully bond the UNDERTONE GREY to sub base. After 8 hours or when adhesive is cured install glue down floor using the same adhesive as the bond coat.