



CARA SAVEN
WALL DESIGN

Installation & Maintenance GUIDE

Preparation

Please ensure your walls are properly prepared and primed (patching any holes and sanding them smooth) for wallpaper.

We provide an overlap in design on all our wallpaper panels that need to be trimmed away. We suggest installing and joining the panels with the seamless joint technique, or by overlapping each panel.

Installation

- Adhesive should be applied to the panel substrate and not on to the wall. This will allow the adhesive to cure with the substrate
- Panels are clearly marked A-Z. Always begin with panel A
- Before working on areas with receptacles, make sure to turn off the power source

Tips

- Position the paper over the outlet or vent and use a razor knife to cut through the paper. Try to leave a little extra paper over the hole so you don't make a gap between the outlet and wallpaper
- Bathrooms can be tricky when it comes to installing wallpaper especially around faucets. We always suggest trying to get your wall mounted faucets taken off before we install, thereby ensuring a faultless installation
- We recommend the wallpaper adhesive ROMAN Pro-880 Ultra clear strippable for installations with any of our CS wallpaper ground substrates

Standard

- Commercial Grade, Type II / Class A wall covering
- The light texture works well to reduce glare from direct light, while adding a warmth to the print
- Medium depth texture, rough surface, low gloss
- Widths: 54", 60", 75"
- Thickness 0.017in to 0.027in
- Contributes to LEED credits v4

Traditional Wallpaper

- Type 1 non-PVC wall covering material
- Light weight and breathable material made from non-woven fabric
- Natural looking, paper feel, with a light hint of a woven texture
- Light texture, smooth surface, very low gloss
- Widths: 54"
- Thickness 0.011in.
- PVS & POA (Olefin) Free

