

# Project Playroom™

## SCREW-ON ROCK WALL HOLDS

Building your own plywood rock wall

### Tools and Materials

- Drill
- Stud finder
- 3/4" thick smooth plywood
- Hardware to apply the plywood to wall studs
- Circular Saw
- Level
- Pencil
- Project Playroom Screw-on Rock Wall Holds with #8 Phillips head countersunk wood screws



### Step 1: Installing Plywood

- Install plywood being sure to center on wall studs
- Caulk and sand nail indents and panel gaps to give the wall a seamless look



### Step 2: Prime & Paint

- This is your opportunity to install wallpaper
- Create your background design before installing holds design before installing holds

### Step 3: Layout & install Rock Holds

- Put time into creating your climbing route!
- We recommend 1 set of (12) screw-on hold for ever 4'x4' wall area for young children.
- You may choose to use less in order to create a difficult route for older children.

