



ULTRA[®]

INSTALLATION INSTRUCTIONS



The Ultra Changing Station Makes One Person Installation Ultra Simple!

When selecting your installation location be aware of ADA guidelines if applicable. Specific ADA compliant sections can be found listed in the changing station instructions

Before we begin, unseal the box and remove the contents. Enclosed is the Changing Station and The EZ Mount Backer Plate, along with all of the screws, anchors, washers, and screw caps needed for installation. Also included is a set of keys and a Liner Starter Kit, including a small stack of liners, for the built-in liner dispenser.

Step One

First we will install the EZ Mount Backer Plate onto the wall. The backer plate will be taped to the back of the unit and looks similar to a metal bar.

Using a studfinder and pencil, mark the area where the studs are on the wall.

Place the EZ Mount Backer Plate flush against the wall where you've marked the studs and make sure it is level.

Note that wood, metal, tile, and concrete block walls have different installation instructions for each type of wall. Use the instructions and diagrams in the packet to determine installation steps for your specific wall type before drilling into the wall.



Step Two

Drill the holes into the areas on the wall that you marked with the pencil using the designated drill bit size. Depending on the type of wall you have, you may need to use an anchor.



Step Three

Line up the Mounting Bracket with the holes you have drilled. You will be screwing the Mounting Bracket into the wall using the Mounting Screws that were included.



Step Four

Place the Screw into the Mounting Bracket and align it with the holes you drilled into the wall. Screw the Mounting Bracket into the wall.



Step Five

Next, hang the lip that's located on the back side of the Changing Station onto the Mounting Bracket making sure that the changing station is secure.

Now that the lip of the Changing Station is securely resting on the Mounting Bracket, you can open the Changing Station.



Step Six

Use a pencil to mark the holes in each corner of the Changing Station. This marks where you'll be drilling holes into the wall for the Changing Station. Take the unit off the bracket and set it aside.



Step Seven

Drill the 4 holes into the wall on the areas that you marked with pencil. Drill the holes into the wall using the appropriate drill bit and mounting hardware for your substrate. You will now be able to put the changing station back on the wall.



Step Eight

You will be using a combination of the washers, screws, and anchors (if necessary) to screw the changing station into the wall in the holes that you have drilled.

Step Nine

Place each Washer on top of the hole you drilled into the wall for each corner of the Changing Station. Then place each Screw through the washer and into the hole.

Screw the Changing Station into the wall.



Step Ten

Repeat this process for all 4 corners.

Step Eleven

Now it's time to add the finishing touches for an ULTRA sleek finish.

Grab the Screw Caps that were included and place them over the holes to cover all 4 of the Screws.



Wow! Now that's an ULTRA sleek finish.



Questions or Comments?

Please contact Customer Service at

[877.716.2757](tel:877.716.2757) (U.S. only) or [330.722.5033](tel:330.722.5033).

Monday-Friday 8:00-5:00 EST