

3D Post™ Patented

Be sure to read and completely understand this procedure before applying product.
Be sure to select the proper Ranchmate® product before application.



Tools Required:

1. Drill (1)
2. 1-1/2" Screws (5)



Ranchmate® products are official FFA® Licensed products.

The FFA® emblem and letters are registered trademarks of the National FFA® Organization™, used under license.

Step #1 Align 3D Post to desired location on the fence post.



Step #2 Using the drill, attach a 1-1/2" screw through the top central hole of the 3D Post to the fence post.



Step #3

Continue this process and attach screws through the four remaining screw holes.



Step #4

Completed installation.



SAFETY CONSIDERATIONS

This application procedure is not intended to supersede any company construction or safety standards. This procedure is offered only to illustrate safe application for the individual. **FAILURE TO FOLLOW THESE PROCEDURES MAY RESULT IN PERSONAL INJURY OR DEATH.**

Do not modify this product under any circumstances.

This product should not be used by anyone who is not familiar with, and not trained to use it.

When working in the area of energized lines, extra care should be taken to prevent accidental electrical contact.

For proper performance and personal safety, be sure to select the proper size Ranchmate® product before application.

Ranchmate® products are precision devices. To insure proper performance, they should be stored in cartons under cover and handled carefully.



P.O. Box 91129, Cleveland, Ohio 44101 • 440.461.5200 • www.ranchmate.com • e-mail: ranchmate@preformed.com

SP3133-2