

KIRAVANS BARN DOOR AWNING - FITTING

1. The metal right angles on the pole ends slot into the door latches and face the van as per photo attached.
2. Then the awning gets tightened around the rubber door seal using the 2 webbing straps to loop under the door hinges.
3. Once this is tight just pass the awning over the door tops and the pole and secure the bungee plastic balls through the lower door latches on each door. Then secure tightly around the pole using the velcro tabs.

