

Single Seat swivels
Compatibility Information



						Compatibility									
Seat Position	Manufacturer code	Kiravans SKU	Product	Compatibility	Includes	Height Increase	Double Passenger SWIVEL Seat <small>Only works if driver seat can rotate fully to the rear. (Vans with furniture behind driver seat will not work.)</small>	Double Passenger FIXED Seat	Heated seats	Seats with Airbags	Fully Electric Seats	TUV Approved	STATUS Approved	Optional Add ons	
VW T5 / T6 Swivels															
DRIVER:	CBTO13RG2C-LK	swivr-13rg2c-gb	VW T5/T6 Single Seat Swivel RIB - Driver (Right Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Raising shims Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x4 + Countersunk hexagon screw 8x40 x2 	43mm	YES Kiravans T5/T6 Double Passenger Swivel (RHID)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	T5/T6 Cab mat	
	CBTO13RG2-GB	swivr-offset-13rg2-gb	VW T5/T6 Single Seat Swivel RIB - Offset Driver (Right Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Raising shims Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x2 + Countersunk hexagon screw 8x20 x2 	43mm	NO Only compatible with central version	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	T5/T6 Cab mat	
	CBTO13RG2C-EURO	swivr-lhd-13rg2c	VW T5/T6 Single Seat Swivel RIB - Driver (Left Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Raising shims Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x4 + Countersunk hexagon screw 8x40 x2 	43mm	YES Kiravans T5/T6 Double Passenger Swivel (RHID)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	T5/T6 Cab mat	
	CBTO13RG2 offset	swivr-lhd-offset-13rg2	VW T5/T6 Single Seat Swivel RIB - Offset Driver (Left Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Raising shims Fixings: Nylon nut M8x4 + Countersunk hexagon screw 8x20 x2 + Countersunk hexagon screw 8x40 x2 	43mm	NO Only compatible with central version	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	T5/T6 Cab mat	
-	Aguti-T5/6-Driver		VW T5/T6 Seat Swivel with Seat Base AGUTI - Driver (Right Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Swivel with seat base Handbrake adapter All fixings included. 	None	YES Kiravans T5/T6 Double Passenger Swivel (RHID)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
PASSENGER:	CBTO13RD2C-GB	swvpax-13rd2c-gb	VW T5/T6 Single Seat Swivel RIB - Passenger (Right Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Does not include raising shims. These are only needed if you intend to fit a larger leisure battery under the passenger seat Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x6 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	Raising shims T5/T6 Cab mat	
	CBTO13RD2-GB	swvpax-offset-13rd2-gb	VW T5/T6 Single Seat Swivel RIB - Offset Passenger (Right Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Does not include raising shims. These are only needed if you intend to fit a larger leisure battery under the passenger seat Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x4 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	Raising shims T5/T6 Cab mat	
	CBTO13RD2C-EURO	swvpax-13rd2c-lhd	VW T5/T6 Single Seat Swivel RIB - Passenger (Left Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Does not include raising shims. These are only needed if you intend to fit a larger leisure battery under the passenger seat Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x6 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	Raising shims T5/T6 Cab mat	
	CBTO13RD2-EURO-offset	SWVPAX-13RD2-LHD-offset-1	VW T5/T6 Single Seat Swivel RIB - Offset Passenger (Left Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Does not include raising shims. These are only needed if you intend to fit a larger leisure battery under the passenger seat Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x4 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	Raising shims T5/T6 Cab mat	
	-	Aguti-T5/6-Pass		VW T5/T6 Seat Swivel with Seat Base AGUTI - Passenger (Right Hand Drive)	VW T5/T6 / VW Caravelle Can also be used as a LHD Driver swivel	<ul style="list-style-type: none"> Swivel with seat base Handbrake adapter 	None	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-
	-	to-safe		VW T5/T6 Seat Base with Safe & Swivel - Passenger (Right Hand Drive)	VW T5/T6 / VW Caravelle	<ul style="list-style-type: none"> Kits do not include bolts as you can use the existing bolts from your seat. If you do not have the original seat bolts, you will need: 4 x M8 x 20 Bolt, 4 x M8 Nylon nut & 4 x Flat Washers. 	None	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
Vauxhall Vivaro / Renault Traffic / Nissan Primastar / NV300 Swivels															
DRIVER:	CBTO11RG2C-GB	swivr-vivaro-11rg2c-gb	Vivaro / Traffic / Primastar X83 (2001-2014) Single Seat Swivel RIB - Driver (Right Hand Drive)	X83 / VIVARO / PRIMASTAR (2001-2014)	<ul style="list-style-type: none"> Fixings: Nylon nut M8 x8 + Countersunk hexagon screw 8x20 x8 + Threaded bolt 8x20 x8 	43mm	YES Kiravans Traffic / Vivaro / Primastar 2001-2014 Double Passenger Swivel (RHID)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
	CBTO11RG2-GB	swivr-vivaro-offset-11rg2-gb	Vivaro / Traffic / Primastar X83 (2001-2014) Single Seat Swivel RIB - Offset Driver (Right Hand Drive)	X83 / VIVARO / PRIMASTAR (2001-2014)	<ul style="list-style-type: none"> Fixings: Nylon nut M8 x8 + Countersunk hexagon screw 8x20 x8 + Threaded bolt 8x20 x8 	43mm	NO Only compatible with central version	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
	CBTO11RG2C-EURO	swivr-vivaro-lhd-11rg2c	Vivaro / Traffic / Primastar X83 (2001-2014) Single Seat Swivel RIB - Driver (Left Hand Drive)	X83 / VIVARO / PRIMASTAR (2001-2014)	<ul style="list-style-type: none"> Fixings: Nylon nut M8 x8 + Countersunk hexagon screw 8x20 x8 + Threaded bolt 8x20 x8 	43mm	YES Kiravans Traffic / Vivaro / Primastar 2001-2014 Double Passenger Swivel (LHD)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
	CBTO20G2GB	swivr-viv-13-20g2c-uk	Vivaro / Traffic / Talento / NV300 X82 (2014+) Single Seat Swivel RIB - Offset Driver (Right Hand Drive)	X82 / TALENTO (since 2014) / VIVARO (2014-2019)	<ul style="list-style-type: none"> Fixings: 4 Countersunk hexagon screw M10x60 + 4 Countersunk hexagon screw M10x18 with threadlocker red + 1 Threaded bolt M8x16 + 1 Threaded bolt M8x16 + 4 Nut M10 + 1 Nylon nuts M8 + 1 Nylon nuts M4 + 1 for plat lg 84 mm BT54E + 2 Raising shims BT54B (tube 35x35x2 lg 392 black) 	43mm	Not available (Only available for 2001-2014)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
CBTO20G2	swivr-viv-13-20g2c-lhd	Vivaro / Traffic / Talento / NV300 X82 (2014+) Single Seat Swivel RIB - Offset Driver (Left Hand Drive)	X82 / TALENTO (since 2014) / VIVARO (2014-2019)	<ul style="list-style-type: none"> Fixings: 4 Countersunk hexagon screw M10x60 + 4 Countersunk hexagon screw M10x18 with threadlocker red + 1 Threaded bolt M8x16 + 1 Threaded bolt M8x16 + 4 Nut M10 + 1 Nylon nuts M8 + 1 Nylon nuts M4 + 1 for plat lg 84 mm BT54E + 2 Raising shims BT54B (tube 35x35x2 lg 392 black) 	43mm	Not available (Only available for 2001-2014)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-		
PASSENGER:	CBTO11RD2C-GB	swvpax-vivaro-11rd2c-gb	Vivaro / Traffic / Primastar X83 (2001-2014) Single Seat Swivel RIB - Passenger (Right Hand Drive)	X83 / VIVARO / PRIMASTAR (2001-2014)	<ul style="list-style-type: none"> Fixings: Nylon nut M8 x8 + Countersunk hexagon screw 8x20 x8 + Threaded bolt 8x20 x8 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
	CBTO11RD2-GB	swvpax-viv-offset-11rd2-gb	Vivaro / Traffic / Primastar X83 (2001-2014) Single Seat Swivel RIB - Offset Passenger (Right Hand Drive)	X83 / VIVARO / PRIMASTAR (2001-2014)	<ul style="list-style-type: none"> Fixings: Nylon nut M8 x8 + Countersunk hexagon screw 8x20 x8 + Threaded bolt 8x20 x8 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
	CBTO11RD2C	swvpax-vivaro-11rd2c-lhd	Vivaro / Traffic / Primastar X83 (2001-2014) Single Seat Swivel RIB - Passenger (Left Hand Drive)	X83 / VIVARO / PRIMASTAR (2001-2014)	<ul style="list-style-type: none"> Fixings: Nylon nut M8 x8 + Countersunk hexagon screw 8x20 x8 + Threaded bolt 8x20 x8 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
	CBTO20D2GB	swvpax-viv-13-20d2c-gb	Vivaro / Traffic / Talento / NV300 X82 (2014+) Single Seat Swivel RIB - Offset Passenger (Right Hand Drive)	X82 / TALENTO (since 2014) / VIVARO (2014-2019)	<ul style="list-style-type: none"> Fixings: Countersunk hexagon screw 10x25 x4 + Nut M10 x4 + Countersunk hexagon screw 10x18 FF x4 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
	CBTO20D2	swvpax-viv-13-20d2c-lhd	Vivaro / Traffic / Talento / NV300 X82 (2014+) Single Seat Swivel RIB - Offset Passenger (Left Hand Drive)	X82 / TALENTO (since 2014) / VIVARO (2014-2019)	<ul style="list-style-type: none"> Fixings: Countersunk hexagon screw 10x25 x4 + Nut M10 x4 + Countersunk hexagon screw 10x18 FF x4 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
Ducato / Jumper / Boxer Swivels															
DRIVER:	CBTO16G2-GB	swivr-ducato	Ducato / Jumper / Boxer X250 (2006+) Single Seat Swivel RIB - Driver Offset (Right Hand Drive)	JUMPER / BOXER / DUCATO since 2006	<ul style="list-style-type: none"> Fixings: Countersunk hexagon screw 8x30 x6 + Countersunk hexagon screw 8x20 x6 + Nylon nut M8 x6 + 2 Raising Shims 	43mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	
PASSENGER:	CBTO16D2-GB	swvpax-ducato	Ducato / Jumper / Boxer X250 (2006+) Single Seat Swivel RIB - Passenger Offset (Right Hand Drive)	JUMPER / BOXER / DUCATO since 2006	<ul style="list-style-type: none"> Fixings: Countersunk hexagon screw 8x30 x6 + Countersunk hexagon screw 8x20 x6 + Nylon nut M8 x6 + 2 Raising Shims 	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	-	-	

Sprinter / Crafter Swivels

DRIVER	CBT015G2-GB	swidriv-sprinter	Sprinter (2006-2016) / VW Crafter (2006-2016) Single Seat Swivel RIB - Driver (Right Hand Drive)	SPRINTER (2006-2016) / CRAFTER (2006-2016)	• Fixings: Nylon nut M10 x4 + Countersunk hexagon screw 10x25 x4 + Countersunk hexagon screw 10x20 x4	43mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
	-	Aguti-Crafter-2017+Driver	VW Crafter (2017+) Single Seat Swivel AGUTI - Driver (Right Hand Drive)	VW CRAFTER (2017+)	• Swivel base • All fixings included.	66mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
PASSENGER	CBT015D2-GB	swipax-sprinter	Sprinter (2006-2016) / VW Crafter (2006-2016) Single Seat Swivel RIB - Passenger (Right Hand Drive)	SPRINTER (2006-2016) / CRAFTER (2006-2016)	• Fixings: Nylon nut M10x4 + Countersunk hexagon screw 10x25 x4 + Countersunk hexagon screw 10x20 x4	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
	-	Aguti-Crafter-2017+Pass	VW Crafter (2017+) Single Seat Swivel AGUTI - Passenger (Right Hand Drive)	VW CRAFTER (2017+)	• Swivel base • All fixings included.	66mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-

Vito / Viano Swivels

DRIVER	CBT014RG2-GB	swidriv-vito	Vito / Viano W639 (2004-2014) Single Seat Swivel RIB - Driver (Right Hand Drive)	VITO / VIANO W639 (2004-2014)	• Fixings: Nylon nut M10 x4 + Countersunk hexagon screw 10x25 x4	43mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
	CBT021RG2-GB	swidriv-vito-15-21g2-gb	Vito/Viano W447 (2015+) / Sprinter M907 (2019+) Single Seat Swivel RIB - Offset Driver (Right Hand Drive)	MERCEDES VITO/ VIANO W447 (since 2015) / SPRINTER M907 since 2019	• Fixings: Threaded bolt 10x20 x4 + Countersunk hexagon screw 10x35 x4 + Nylon nut M10 x4	43mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
PASSENGER	CBT014RD2-GB	swipax-vito	Vito / Viano W639 (2004-2014) Single Seat Swivel RIB - Passenger (Right Hand Drive)	VITO / VIANO W639 (2004-2014)	• Fixings: Nylon nut M10 x4 + Countersunk hexagon screw 10x25 x4	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
	CBT021RD2-GB	swipax-vito-15-21d2-gb	Vito/Viano W447 (2015+) / Sprinter M907 (2019+) Single Seat Swivel RIB - Offset Passenger (Right Hand Drive)	MERCEDES VITO/ VIANO W447 (since 2015) / SPRINTER M907 since 2019	• Fixings: Threaded bolt 10x20 x4 + Countersunk hexagon screw 10x35 x4 + Nylon nut M10 x4	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-

Master / Movano / NV 400 Swivels

DRIVER	CBT018G2C-GB	swidriv-master62-18g2c-gb	Renault Master X62 / Movano/ NV400 (2010+) Single Seat Swivel RIB - Driver (Right Hand Drive)	MASTER X62 / MOVANO / NV 400 (since 2010)	• Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x4 + Threaded bolt 8x20 + Washer 10x27x2 x10 + Threaded bolt 10x35 x2	43mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
PASSENGER	CBT018D2C-GB	swipax-master62-18d2c-gb	Renault Master X62 / Movano/ NV400 (2010+) Single Seat Swivel RIB - Passenger (Right Hand Drive)	MASTER X62 / MOVANO / NV 400 (since 2010)	• Fixings: Nylon nut M8 x4 + Countersunk hexagon screw 8x20 x4 + Threaded bolt 8x20 x4	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-

Transit / Transit Custom Swivels

DRIVER	CBT019G2C-GB & ACAFMTC	swidriv-transit-2013+	Transit Custom V362 (2013+) / Transit V363 (2014+) Single Seat Swivel RIB - Driver (Right Hand Drive)	TRANSIT CUSTOM V362 (since 2013) / TRANSIT V363 (since 2014)	• Handbrake lowering kit (3 Threaded bolt M8x20 + 3 Countersunk hexagon screw M8x20 + 6 Nylon nuts M8) • Fixings: Threaded bolt 8x20 X4 + Countersunk hexagon screw 8x20 X4 + Nylon nut M8 X4 + Contact washer M8 x4	43mm	Not available (Only available for 2006-2013 Transit)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
PASSENGER	CBT019D2C-GB	swipax-transit-2013+	Transit Custom V362 (2013+) / Transit V363 (2014+) Single Seat Swivel RIB - Passenger (Right Hand Drive)	TRANSIT CUSTOM V362 (since 2013) / TRANSIT V363 (since 2014)	• Fixings: Threaded bolt 8x20 X4 + Countersunk hexagon screw 8x20 X4 + Nylon nut M8 X4 + Contact washer M8 x4	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-

Scudo / Expert / Dispatch / ProAce Swivels

DRIVER	CBT017G2-GB	swidriv-scudo	Scudo G9 / Expert / Dispatch / ProAce (2007-2016) Single Seat Swivel RIB - Driver (Right Hand Drive)	JUMPY (Dispatch) / EXPERT / SCUDO G9 / PROACE (2007-2016)	• Fixings: Nylon nut M8x6 + Countersunk hexagon screw 8x16 x6 + Threaded bolt 8x20 x6	43mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
	CBT022G2GB	swidriv-scudo-2016	Expert K0 / Dispatch / ProAce (2016+) Single Seat Swivel RIB - Driver (Right Hand Drive)	JUMPY (Dispatch) / EXPERT K0 / PROACE (since 2016) / VIVARO (since 2019) / SPACETOURER / TRAVELLER (since 2019)	• Fixings: 2 Dome head hex screw M8x12 + 2 Contact washers M8x18 + 8 Washers M10x27x2 + 2 Hex serrated flange nut M10 + 8 Nylon nuts M10 + 6 Countersunk hexagon screw M10x25 + 5 Nylon nuts M8 • 5 Dome head hex screw M8x16 + 2 Threaded bolt M10x25 + 1 BT57A-ST (1 flanc D + 1 flanc G + 1 Steel angle + 4 Spacers lg 30) + 1 BT57CD-ST Handbrake support D (attention version D/G 1)	43mm	Not available	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
PASSENGER	CBT017D2-GB	swipax-scudo	Scudo G9 / Expert / Dispatch / ProAce (2007-2016) Single Seat Swivel RIB - Passenger (Right Hand Drive)	JUMPY (Dispatch) / EXPERT / SCUDO G9 / PROACE (2007-2016)	• Fixings: Nylon nut M8 x6 + Countersunk hexagon screw 8x20 x6 + Threaded bolt 8x20 x6	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-
	CBT022D2GB	swipax-scudo-2016	Expert K0 / Dispatch / ProAce (2016+) / Vivaro (2019+) Single Seat Swivel RIB - Passenger (Right Hand Drive)	JUMPY (Dispatch) / EXPERT K0 / PROACE (since 2016) / VIVARO (since 2019) / SPACETOURER / TRAVELLER (since 2019)	• Fixings: 2 Dome head hex screw M8x12 + 2 Contact washers M8x18 + 8 Washers M10x27x2 + 2 Hex serrated flange nut M10 + 8 Nylon nuts M10 + 6 Countersunk hexagon screw M10x25 + 2 Nylon nuts M8 • 2 Dome head hex screw M8x16 + 2 Threaded bolt M10x25 + 1 BT57A-ST (1 flanc D + 1 flanc G + 1 Steel angle + 4 Spacers lg 30)	23mm	N/A	N/A	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-	-