

JIMNY DIFF BREATHER KIT

Tuesday, 28 February 2023 11:06 AM



- | | |
|-----------|---|
| STEP ONE: | Pull the factory cap off with pliers and replace with hose section and hose clamps with the brass right angle fitting as shown. (tip; offset the hose clamps and ensure the brass fitting is pushed in all the way) |
| STEP TWO: | Install the push-fit diff breather fitting into the brass right angle, insert diff breather hose and run securely (keep away from moving or hot components) (We add split tubing on ours which is not included in the kits) |



- | | |
|-------------|--|
| STEP THREE: | Repeat the step on the other diff. (tip; offset the hose clamps and ensure the brass fitting is pushed in all the way) (keep away from moving or hot components) (We add split tubing on ours which is not included in the kits) |
| STEP FOUR: | Run and secure all cabling and Install the filter housing securely, we made a bracket to mount ours so we don't have to drill into the body. (bracket not supplied in kit) |

