

Jimny Heavy-Duty Slide Fitment Instructions

Installation Time:

Single Slide 30 min
Double Slide 70 min



welcome to the Bushtech family.

This fitment instruction will guide you through each process to mount the Suzuki Jimny Heavy-Duty Slide.

The Heavy-Duty slider allows you to mount a fridge onto the slider, allowing you to gain access to your fridge without removing the fridge from the car.

The Heavy-Duty Slide has been designed to be mounted on top of our **Mounting Frames.** Please ensure you have purchased and installed this item for your slider.

Let's get started.

What's in the box:



- 1 x Heavy-Duty Slide.
- 2 x Slide Supports.
- 2 x M8 x 20mm Bolts
- 2 x M8 x 40mm Bolts.
- 4x M8 x 19mm Washer.
- 2 x M6 x 20mm Bolts
- 2 x M6 x 19mm Washers
- 4 x M8 Square Nut.

Tools you need:



- 1 x Ratchet.
- 1 x Ratchet Extension.
- 1 x Size 13 Socket.
- 1 x 13mm Spanner.

Step 1:

Open the slider and secure the two slide supports to the frame with $2 \times M8 \times 20 \text{mm}$ Bolts and the 19mm washers provided.



Step 2:

Next place the heavy-duty slide on top of the Mounting Frames. (Your **Bushtech** Mounting Frames must be fitted before proceeding with this installation.)





Step 3:

With the M8 x 40mm bolts and M8 x 30mm washer supplied, secure the slide supports to the mounting frame situated on top of the foot-well of the rear pasenger seats.





A square nut supplied is placed inside the mounting frame. The frame will hold the nut while you tighten the M8 x 40mm bolt. Do not secure the two/2 slide supports at this point only hand tighten the bolts into place as the slide will need to be positioned.



Step 4:

Moving to the boot side again, pull open the slide till it locks open.



With the use of the remaining M8 x 20mm Bolts and nuts. hand-tighten the slide to the rear mounting bracket.





Step 5:

Close the slide and adjust the slide left or right to ensure the seat next to the slide can be opened and closed.





Step 6:

Once you are happy with the position of your slide, start by securing the slide supports first, then open the slide and secure the bolts to the rear mounting frame in the boot.



Two/2 Slides can be fitted into your Suzuki Jimny. Please see images below.

The second slide is installed with the same methods mentioned above.





Note: An extension shock will need to be installed onto the back door to ensure the door opens wide enough for the slide to open. The extension shock fitment instructions will guide you through the steps needed to replace the back door shock.









Disclaimers:

- It is imperative that all Bushtech accessories are correctly fitted and secured to your vehicle.
- Negligent installation of the accessories could lead to a critical vehicle accident, which may cause severe injurie or even lead to the demise of others.
- Once fitted the accessories should be checked on a regular basis and if need be, adjusted and secured. This is the owner's responsibility.
- Before you begin installing your accessory, it is vital that you read and understand the fitment instructions and be ready for the installation.
- Should you not fully understand the installation instructions, and you are concerned that you do not have the technical or mechanical know-how, it would be in your best interest to have the accessory fitted by Bushtech or an approved Bushtech fitment Centre.