

1999 Destiny Series Interior 12 Volt Trailer Wiring Diagram (Redwood & Santee)

NOTE: FIRST CODE OF 1999 REDWOODS HAD THE PORCH LIGHT CONNECTED AFTER THE KILL SWITCH

