FLEETWOOD FOLDING TRAILERS, INC. INSTALLATION INSTRUCTIONS

1968D501 May 2003

MODEL NUMBER: 4758A5261 BED SHELF

This kit is for use on all 1998 to current year models, except the Taos.

NOTE: On 2001 to present models, the bed bow is pre-drilled.

This kit contains:

4758-526 Shelf assembly

1203-883

Rivet 4751-343 Nylon spacers

IMPORIDANT NOTE (OE

These instructions are for the use of qualified individuals specifically frained and experienced in the installation of this type equipment. Persons not qualified shall not attempt to install this equipment nor interpret these instructions.

- 1 With trailer in open position, remove bed canvas from bed assembly and fold inside trailer. Remove mattress from bed to prevent damage. Pull canvas to inside of trailer to open bed area for installation. Fold canvas support toward inside of trailer.
- 2. Remove retaining screw from bed bow support bracket (triangle shaped) mounted to the side of the bed frame. Pull bed bow away from bracket to allow support to spread. Do not spread bed bow more than one inch.
- 3. Insert nylon spacers over shelf pins and carefully insert shelf pins into bottom pre-drilled holes in canvas support. Do not scratch paint off of bed bow. Be sure shelf is positioned with open side up. If holes are not pre-drilled, you will need to drill those holes using the diagram that is provided.

IMPORTANT: Metal shavings must be removed from bed support prior to reinstalling mattress assembly.

- 4. Using the two rivets supplied, rivet the support cables to the canvas support using the upper pre-drilled hóles.
- 5. Reassemble bed bow to bracket and attach with original retaining screw.
- 6. Replace mattress assembly.
- 7. Reattach canvas to bed.

CAUTION: When closing trailer, bed shelf must lie flat on the mattress to prevent damage to the tenting and/or mattress.

