

**FLEETWOOD FOLDING TRAILERS, INC.**  
**INSTALLATION INSTRUCTIONS**

1968D443  
August 2002

**PART NUMBER 4753A6771 - MOLDED SPARE TIRE COVER**

**For Use On: 2000 through current model Grand Tour Series Models**  
**2000 through current model Grand Tour Elite Series Models**

**This kit contains:**

- 1 - 4753-365 Top keeper bracket
- 1 - 1121C1606 Screw
- 1 - 4732-118 Grommet
- 3 - 1203-864 Rivet
- 1 - 1202B026 Washer
- 3 - 4741D9656 Expansion rivet
- 1 - 4757A171 Tire cover
- 2 - 4747-255 Expansion rivet
- 1 - 1202E040 Washer
- 1 - 4752C078 Coleman/Fleetwood logo

**IMPORTANT NOTICE**

**These instructions are for the use of qualified individuals specifically trained and experienced in the installation of this type equipment. Persons not qualified shall not attempt to install this equipment nor interpret these instructions.**

**INSTALLATION INSTRUCTIONS**

1. Using the three rivets provided, rivet the hinge attached to the spare tire cover to the bumper of the trailer. The portion of the hinge riveted to the bumper will be inside the spare tire cover when closed. (See diagram)

**NOTE:** The pre-drilled holes in the bumper **must** be 7/16" from the edge of the bumper closest to the rear body panel.

2. Using the attached drawing, mark and drill three 3/16" holes for mounting the keeper bracket and the cable.
3. Using two of the expansion rivets provided, attach the keeper bracket to the pre-drilled holes in step #2 located near the top of the spare tire indentation on the rear body panel. (See diagram) Insert grommet in square cutout in keeper bracket. The grommet should be installed from the top of the keeper bracket.
4. Using the remaining expansion rivet and washer, attach the cable from the spare tire cover to the pre-drilled hole on the left-hand side of the spare tire indentation on the rear body panel. (See diagram)

5. Install the spare tire mount bolts (not supplied with this kit) in the holes located in the center of the spare tire indentation on the rear body panel. Place spare tire on bolts and fasten with lug nuts from spare tire mount bolt kit.
6. Close the spare tire cover. Place the screw provided down through the pre-drilled hole in the top of the spare tire cover and through the grommet in the keeper bracket. Tighten securely.

