FLEETWOOD FOLDING TRAILERS, INC. DRAPERY INSTALLATION INSTRUCTIONS

1968D413 October 1997

			DESTINY SERIES		GRAF	OD TOUR SERIES	
FO	RM	ODEL(S):	()	Taos	()	Bayside	
			()	Redwood	()	Grandview	
			()	Sea Pine	()	Sun Ridge	
			()	Santa Fe	()	Niagara	
			()	Cheyenne	()	Grandview SP	
			()	Westlake	()	Casa Grande	
			()	Mesa			
			()	Rio Grande			
			()	Nachez			
THIS PACKAGE CONTAINS:							
3		Roadside panels on Sea Pine, Santa Fe, Cheyenne, Mesa, Rio, and Sun Ridge (OR)					
2							ď
		Niagara, and Casa Gran	de		,		9
				(AND)			
2	Exception. Diape package for Nachez consists (or Nachez consists of 2 large	
					ear and	2 small panels (22") for curbsic	le
2		0-6-4-4-1		front.			
2		Safety track stop screws	3				
1		Package of tiebacks					
1	019	Piece adhesive-backed	relcro (Sun Valley and Sun R	idge m	odels only)	

INSTRUCTIONS

- 1. Separate roadside and curbside drape panels.
- 2. Snap the plastic "C-shaped" tabs, sewn on the back of the drapes, to the drape track located directly above where the Sunbrella attaches to the roof. Do this for both the roadside and curbside drape panels.

NOTE: Drape panels are intended to fit all the way to the top corners.

- 3. On Sun Valley and Sun Ridge models, attach the adhesive-backed velcro to the lift pocket nearest to the galley. This velcro will attach to the velcro sewn to the 15" drape panel.
- 4. <u>Taos and Redwood Only:</u> The drape panel behind the stove will have velcro tabs sewn on the bottom. Separate the self-adhesive velcro tabs from the bottom of the drape ties. Attach the self-adhesive velcro to the back of the galley in a position that corresponds with velcro sewn on the drape panel. <u>The drape ties then adhere to the velcro tabs placed on the back of the galley prohibiting the drape panel from entering the stove area.</u>

<u>All others:</u> Slide the ties on the bottom of the stove drape panel into the small plastic track attached to the top of the roadside body rail (directly behind the galley). <u>These ties are to prevent the drapes from blowing into the stove.</u> Insert the safety screws supplied into the pre-drilled holes in the ends of the plastic track preventing the ties from exiting the track.

NOTE: Be sure to remove the drape ties from the safety track or velcro attachments prior to closing the galley or beds.

5. Wrap the tieback around the drape panel and insert one end through the Sunbrella loop. Secure the two ends of the tiebacks together using the velcro tabs or buttons attached. On 10' and 12' trailers there will also be a tieback for the roadside center drape panel which simply wraps around the drape and attaches to itself with the velcro or buttons attached to each end.