

INSTALLATION INSTRUCTIONS

Installation Instructions For:

FRONT STORAGE LID ASSEMBLY

I

FRONT STORAGE LID HINGE

	THOM STOREGE BID HINGE	
LIE	<u>INSTALLATION</u>	A
1.	Remove the set screw located at the center of the front storage compartment body rail.	の重成
2.	Slide the storage lid and hinge assembly out.	ing.
3. 🦠	Set the new lid assembly in place and center it:left to right. Locate the piano hinge atop the front body rail flange.	42
4	Locate the hinge center and fasten the piano hinge to the flange using one tek screw (4744A05	5(
	NOTE: Ensure the hinge is pushed back tightly against the front body rail.	
5	Evenly space four additional tek screws (4744A050) across the hinge (two on each side of the center screw).	
HIN	IGE INSTALLATION	\$10.7°
1.	Remove the set screw located at the center of the front storage compartment body rail.	李
2.	Slide the lid and plastic hinge assembly out.	¢
3.	Drill off the rivets to remove the plastic hinge. Disgard the plastic hinge and hinge angle.	
4.6	Center the new piano hinge (4753-316) left to right. Be sure the side with the angle is located under the lid (angle down).	
5.	Use the holes already in the lid to drill and rivet the piano hinge fast.	
6.	Set the lid assembly in place and center it left to right. Locate the piano hinge atop the front body rail flange.	. (

Evenly space four additional tek screws (4744A050) across the hinge (2 on each side of the cent screw).

Area Locate the hinge center and fasten the piano hinge to the flange using one tek screw (4744A050

NOTE: Ensure the hinge is pushed back-tightly against the front body rail

9.13 Lift the lid and prop it in place with the prop rod. Place a bead of caulking along the angle on the metal hinge. Leave the lid up until the caulking is dry.

1