



CAMPING TRAILERS

INSTALLATION INSTRUCTIONS

Model Number 4744-4641 - Stone Guard Kit (Used on all Pioneer Series Camping Trailers)

This kit contains:

- a. 2 - 4744-464 Stone guard material
- b. 1 - 4737B363 Caution decal
- c. 1 - 4730F318 Open decal

INSTRUCTIONS

1. Remove both roadside and curbside front body panel corner moldings.
2. Remove the gas piping decal (located above the roadside frame bar) and the open and caution decals (located at the upper crank).
3. Remove the upper crank cover plate.
4. To locate the hole in the stone guard material for the upper crankshaft, measure down from the upper body rail and in from the edge of the front body panel to the center of the upper crankshaft. Using these measurements, mark one sheet of stone guard material and cut a 1" diameter hole for the upper crankshaft.
5. To locate the cutout for the frame bar, measure from the outer curbside edge of the front panel to both sides of the frame bar. Mark these locations on the bottom of the sheet of stone guard material from Step 4. Make a mark 19" down from the top of the stone guard material between the two marks previously described. Using these marks, cut out a rectangle to the bottom edge of the stone guard material.
6. Using the other sheet of stone guard material, follow the instructions in Step 5 to make a cutout for the roadside frame bar.
7. Clean the front panel to remove any dirt or grime.
8. Starting at the top edge of the roadside stone guard material, peel back 2" to 3" of the backing paper. Place the top edge of the sheet against the bottom edge of the upper body rail making certain the side of the sheet stays even with the outer edge of the front panel.
9. Using a squeegee, work down the panel peeling back small amounts of the baking paper at a time.

Note: If any air bubbles appear, puncture with a needle or pin and press down with a squeegee.
10. Repeat Steps 8 and 9 for curbside of the trailer.

Note: Use care when placing the stone guard material around the upper crank and frame bars.
11. Place decals in package at original locations on stone guards using a brush to insure good adhesion.
12. Replace both roadside and curbside front body panel corner moldings.
13. Replace the upper crank cover plate.