

WALL
(IN-BETWEEN JOIST IN A 2"x4" or 2"x6" STUD WALL)

- HELPS TO REDUCE BASEMENT DAMPNESS AND INCREASES COMFORT
- REDUCES HEAT LOSS TO THE SURROUNDING ENVIRONMENT
- EXCELLENT VAPOR AND RADON BARRIER
- UNAFFECTED BY MOISTURE AND HUMIDITY
- QUICK AND EASY TO INSTALL

INSTALLATION METHOD

1. Unroll EcoFoil® insulation inside the stud cavity at the midpoint of the 3 1/2" side of the 2-by-4 wood studs spaced at 16" on center.
2. Staple the EcoFoil® insulation along the staple tabs and affix to the studs.
3. Seal all edges with EcoFoil® tape to ensure a continuous insulation and vapor barrier.
4. Install drywall as per the usual method. The recessed insulation material will create the necessary airspace require for reflective insulation.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

EcoFoil® Insulation Product	EF2222 Series (Available in Various Dimensions)
EcoFoil® Tape	EF15073 (Reflective)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.

